

Simple Serve Bottle Warmer

To Clean:

Water vial: Dishwasher safe (top rack only).

Baskets, adapter ring: Dishwasher safe (top rack only).

Sanitizer lid: Dishwasher safe (top rack only).

Bottle warmer unit: ALWAYS TURN OFF AND UNPLUG BEFORE CLEANING. Wipe surface of unit as well as inside warming chamber with a damp cloth or sponge using mild liquid soap. Wipe with clear water. Air dry. DO NOT IMMERSE BOTTLE WARMER IN WATER. Do not use scouring pads, solvents or abrasive cleaners as they could damage the unit.

Warming chamber: Mineral deposits (usually white in color) may form on the inner surfaces of the warming chamber and can cause damage to the unit.

To remove mineral deposits:

1. Unplug the unit.
2. Remove the basket and wash separately as indicated above.
3. Pour 2 oz. vinegar into the warming chamber and let it stand for an hour or two (longer if necessary).
4. Pour out the vinegar and rinse the chamber two or three times with 3 or 4 oz. of clear tap water.

Do not immerse the Bottle Warmer in water. Wipe dry or air dry.

Night Cravings Bottle Warmer & Cooler

To Clean:

Water vial: Dishwasher safe (top rack only).

Baskets, adapter ring, freezer bottle: Dishwasher safe (top rack only).

Sanitizer lid: Dishwasher safe (top rack only).

Bottle warmer unit: ALWAYS TURN OFF AND UNPLUG BEFORE CLEANING. Wipe surface of unit as well as inside warming chamber with a damp cloth or sponge using mild liquid soap. Wipe with clear water. Air dry. DO NOT IMMERSE BOTTLE WARMER IN WATER. Do not use scouring pads, solvents or abrasive cleaners as they could damage the unit.

Warming chamber: Mineral deposits (usually white in color) may form on the inner surfaces of the warming chamber and can cause damage to the unit.

To remove mineral deposits:

1. Unplug the unit.
2. Remove the basket and wash separately as indicated above.
3. Pour 2 oz. vinegar into the warming chamber and let it stand for an hour or two (longer if necessary).
4. Pour out the vinegar and rinse the chamber two or three times with 3 or 4 oz. of clear tap water.

Do not immerse the Bottle Warmer in water. Wipe dry or air dry.